Megger.

OTS80PB and OTS60PB Portable oil test sets



- Light-weight, rugged, portable instruments for measuring insulating oil breakdown voltage
- Lock in precision oil vessel with lockable adjustment
- Bright 3.5 inch colour display visable out doors
- Suitable for mineral, ester and silicon oils
- Trip detection circuit with direct measure ment of voltage and current
- Ultra fast (<10 µs) HV switch off time

DESCRIPTION

Megger's automatic portable oil test sets perform accurate breakdown voltage tests on mineral, ester and silicon insulating liquids. Moulded test vessels give repeatable results in the field and laboratory with lock in precision electrode gap setting adjustment wheels. The transparent, shielded lid is a key feature enabling users to see what is happening within the test chamber.

Megger portable 60 kV and 80 kV oil test sets are the lightest on the market ranging from 16 kg to 23.5 kg depending on model and configuration. They come complete with optional carry bag and transport case. The carry bag has pouches for electrode accessory pack, leads, quick user guide, paper roll etc.

The units are mains powered with optional lead acid or NiMH batteries. In addition, an internal 12 V DC charger and vehicle adaptor cable is standard with either battery option.

Test standards are preloaded in the instrument and new versions can be uploaded via USB flash drive. Both portable instruments support the creation of user defined custom tests. Test results are identified either by a serial number or asset ID and are time and date stamped.

An optional internal printer provides a hard copy of results. Ink based printout ensures durability at all temperatures. USB interfaces (x3) support PC connection, USB flash drive, external USB printer and barcode scanner.

User safety is paramount and Megger have designed independent and dual redundant high voltage cut-off circuitry to ensure safety. During a test the operator can terminate by pressing any button on the keyboard which will remove high voltage immediately and abort the test. The transparent lid provides ample visibility within the chamber yet is protected and electrically shielded by a screen with

multiple links to instrument ground.

FEATURES AND BENEFITS

- Test voltages up to 60 kV or 80 kV
- Lock in precision oil vessel lockable gap setting
- Flat electrode gap gauges that will not damage electrodes
- Automatic oil temperature measurement
- QVGA colour display with backlight
- Easy clean chamber with oil drain
- Safe operation with dual redundant micro-switch HV cut off, zero volt touch bar and screened lid
- Transparent lid results in highly visable test chamber and vessel
- Intuitive user interface supports fully automatic operation with preloaded international test standards plus user configurable test sequences

OPTIONAL ITEMS

- Factory fitted lead-acid (OTS80PB only) or NiMH battery with 12 V charger and vehicle lead
- Internal printer
- Motorised lid impeller
- Voltage check unit (VCM100D)
- Carry bag
- Transport case

APPLICATION

Monitoring and maintenance of oil quality is essential in ensuring the reliable operation of oil filled electrical equipment. Codes of practice have been established in many countries that include several different types of test on insulating oils.

One of the fundamental tests of oil quality is the breakdown voltage test, which is a measure of the oil's ability to withstand electric stress. A low breakdown voltage can indicate the presence of contaminants such as water or conducting particles.

80% RH at 40 °C operation

95% RH at 40 °C storage

Humidity

Safety

FMC

and CISPR 16-2

Designed in accordance with IEC61010

Light industrial IEC 61326-1 Class B, CISPR 22, CISPR 16-1



Care should be taken to ensure the process of sampling oil and subsequent testing does not in any way contaminate it with foreign objects. Cleaning vessels between oil tests should be a rinse with the next sample, never clean with fibrous materials. To ensure an accurate reading set gap carefully and lock adjusting wheels.

SPECIFICATIONS

Test voltage

OTS 60PB -30 to +30 kVrms

OTS 80PB -40 to +40 kVrms

Voltage resolution 0.1 kV, $\pm 1\%$, ± 2 digits

Programmed test sequences

ASTM D 1816-04 ASTM D 877A-02 ASTM D 877B-02 IEC 60156-95

Vessels 400 ml (standard) 150 ml (option)

Nylon 12 chamber provides precision electrode alignment and adjustment wheels lock electrodes in position, option of 150 ml vessel for

low volume oil samples

Temperature sensor resolution

1 °C

Power supply Line voltage 85 to 265 VAC

Line frequency 50/60 Hz

Batteries (option) Lead acid 2 x 12 V 4 Ah,

or NiMH 24 V 2 Ah

Interfaces USB 2.0 compatible

2 x USB type-A (memory stick) 1 x USB type-B (printer or PC)

Internal Printer (option)

Matrix impact printer Paper 57.5 mm wide

External printer Any printer with USB interface and

PCL3 driver

Protection Safety interlock on cover

Display 320 x 240 QVGA colour display with

backlight

Dimensions

 OTS 60PB
 520 mm x 340 mm x 250 mm

 OTS 80PB
 520 mm x 380 mm x 250 mm

Weight

OTS 60PB 16 kg (printer, no battery),

16.8 kg (printer, NiMH battery)

OTS 80PB 20 kg (printer, no battery),

20.8 kg (printer, NiMH battery), 23.2 kg (printer, lead acid batteries)

Test vessels 1.1 kg (400 ml and 150 ml)

Environmental

Operating temperature 0 °C to +50 °C

Storage temperature -30 °C to +65 °C



VCM100D



400 ml vessel assembly (electrodes fitted)



ORDERING CONFIGURATION

Example of an ordering configuration:-

OTS80PB-EU2-EP-4C = This order is for an OTS80PB with EU power lead, NiMH battery, IEC electrode set, internal printer, lid stirrer and carry bag.

Model:	отѕ		PB-		-		-		
									Weights
Select Model	80 kV	80							19.4 kg
	60 kV	60							15.3 kg
Select Power Cord	-	EU Lead	EU						
	-	UK Lead	UK						
	P	US Lead	US						
	*	Australian Lead	AU						
		No Plug Lead	BL						
Select Battery Option			Sealed Lead Acid	1 OTS80PB ONLY					3.3 kg
			NiMH	2					0.8 kg
	NONE		No Battery	х		_			0 kg
	41	11		ASTM Set	А				
Select Electrode Set	••	11		IEC Set	E				
	•	11	41	Full Set	U		_		
Select Printer Option			0		Internal Printer	Р			0.54 kg
					No Printer	х			0.08 kg
Select Stirrer Option				a	3	Stirrer Lid Assembly Fitted	4		0.3 kg
				>	K	Stirrer Lid Assembly Not Fitted	х		
Select							Carry Case	С	1.3 kg
Carry Case Option						<	No Carry Case	х	



OR	DERING I	NFORMATION	
Product Or	der Code	Product	Order Code
Included Accessories		Full electrode set ASTM and IEC electrodes	1001-479
Vessel 400 ml assembly		Vessel lid mounted impeller (ASTM D1816) for use	
12 V vehicle charger lead (supplied only on instrumer	nts	with 400 ml vessel	1001-102
configured with a battery)		Carry bag (padded) OTS80PB	1001-476
Magnetic bead stirrers (2 off)		Carry bag (padded) OTS60PB	1001-480
Magnetic bead retriever		Optional accessories	
Feeler gauge set 1, 2, 2.5, 2.54 mm		Transport case (with wheels)	1001-475
User manual		Vessel 400 ml assembly	
Configured accessories (to order additional or spares)		(no electrodes supplied)	1001-473
IEC60156 Electrode Set - 12.7 mm spherical (2),		Vessel 150 ml assembly	
36 mm mushroom (2)	1001-477	(no electrodes supplied)	1001-474
ASTM D877/1816 electrode set - 25.4 mm cylindrical		VCMD Digital calibration meter	1001-105
(2 std, and 2 none std), 36 mm mushroom (2)	1001-478	Printer paper, 1 roll (MOV applies) (4 rolls supplied	
		if printer configured)	25995-001

Archcliffe Road Dover CT17 9EN England T +44 (0) 1304 502101 F +44 (0) 1304 207342 UKsales@megger.com

UNITED STATES

4271 Bronze Way
Dallas TX 75237-1019 USA
T 800 723 2861 (USA only)
T +1 214 333 3201
F +1 214 331 7399
USsales@megger.com

OTHER TECHNICAL SALES OFFICES

Valley Forge USA, College Station USA, Sydney AUSTRALIA, Täby SWEDEN, Ontario CANADA, Trappes FRANCE, Oberursel GERMANY, Aargau SWITZERLAND, Kingdom of BAHRAIN, Mumbai INDIA, Johannesburg SOUTH AFRICA, Chonburi THAILAND

Registered to ISO 9001:2000 Cert. no. Q 09290 Registered to ISO 14001-1996 Cert. no. EMS 61597